

CRAFT DISTON


Capri Series Tub / Shower Enclosure

INSTALLATION INSTRUCTIONS

Model Numbers

| | |
|---------------|------------------|
| Tub Enclosure | Shower Enclosure |
| 58D | 76D |

(2) by-passing doors



To install your shower enclosure, you will need the following:

- level
- 3/32", 1/8" and 3/16" drill bits
- phillips screwdriver
- sealant


GLAZED
includes glass

KD
does not
include glass

NOTE: K.D. units include all metal parts and hardware, but do not include glass. Glass size equals frame size less 1 1/2" in height and width.


| Description | Qty. | Part # | |
|---|--------------|-------------------|--|
| 1. Track (part # SSI-122 used in Clean Track models) | 1 or 1 | SSI-64 SSI-122 | |
| 2. Wall jamba | 2 | SSI-163 | |
| 3. Wall anchors | 6 | NO240 | |
| 4. #8 x 1" PH SMS | 6 | 300 | |
| 5. Bumpers (four with Clean Track Models) | 2 | NO220 | |
| 6. Header | 1 | SSI-226 | |
| 7. Rollers | 4 | NO260 | |
| 8. #8-32 x 3/8" TH MS | 12 | 302 | |
| 9. Towel bar brackets | 4 | 212 | |
| 10. Towel bars (double) | 4 | SSI-40 | |
| 11. Nylon door guides (used in Standard Track models) | 4 | NO230 | |
| 12. Vinyl door guide (used in Clean Track Models) | 1 | NO261 | |
| 13. Track silencer (used in Clean Track Models) | 2 | V2630 | |
| 14. Tempered glass (glazed units) | 2 | | |
| 15. Glazing vinyl | 34 ft. | | |
| 16. Top door frames | 2 | SSI-75 | |
| 17. Side & bottom door frames | 6 | SSI-78 | |
| 18. Corner brackets | 8 | SS202 | |
| 19. #8-32 x 1/2" PH MS | 16 | 301 | |
| 20. Jamb guide | 2 | VL163 | |

Corner Detail



When Ordering Repair Parts, Please Give The Following Information:

1. Part Number
2. Part Name
3. Model Number
4. Specify design, if any



Step 1


MODELS 58D / 78D

Standard track models

- measure the wall to wall opening on the tub rim.
- cut track 3/16" less than opening

Clean track models


- position vinyl guide (12) in the exact center of track with track silencer (13) lightly against either side of vinyl guide.
- trim excess at each end of track.



Step 2


- place track (1) on center of curb with weep holes to inside of shower.
- set jamba (2) firmly in track next to wall.
- plumb and mark installation holes on wall.

Note: It is important that the wall jamba are plumb.




Step 3

- remove all parts.
- for ceramic tile installation, use a 3/16" masonry bit for drilling installation holes and install plastic wall anchors (3).
- for fiberglass walls, use a 9/64" drill bit for drilling installation holes.




Step 4

- apply a continuous bead of sealant to the underside of track (1).
 - replace track in previous location and apply sealant to both ends where track meets wall.
 - replace jamba (2) and secure to wall with six #8 x 1" pan head sheet metal screws (4).
- NOTE:** Use center screws to install bumpers (5).



Step 5

- measure the wall to wall opening above the wall jamba.
- cut header (6) 1/16" less than opening.
- place header over jamba (2).




Step 6

- attach rollers (7) to top of doors with four #8-32 x 3/8" truss head sheet metal screws (8) as shown.



Step 7

- fit door into header, placing rollers down in track. Do the same for other door.



Step 8

- insert towel bar ends (10) into towel bar brackets (9).
- insert #8-32 x 3/8" truss head machine screws (8) through shower door side frame and into towel bar bracket.
- install the by-pass door stop (21) on the inside of the outside panel farthest from the shower head. It can also be installed on the outside of the inside panel next to the shower head.
- towel bars are to be attached to the outside of the outside door and to the inside of the inside door to allow the doors to pass each other freely.

Step 9

- seal inside and outside of unit at any point unit meets wall or curb.